

White PVC Demo Counter (Code: PPCD-190-CGW)

Easy Set Up Instruction

(Please read before set up)



<http://www.prints-mart.com>



Step 1 : Remove the components from the nylon carrying bag.



Step 2 : Take one **A) Top/Base Unit (the larger piece)** as the base unit. Place on the floor with the raw edge facing upwards.



Step 3 : Slot the two **D) Shelf Unit Supporting Pole (the shorter pole with screw at the end)** into the holes of the bottom unit.



Step 4 : The base unit with two shelf unit supporting poles facing up on the floor.



Step 5 : Unfold the **(C) Bottom Panel (Graphic Wrap)**. Slot into the base unit opening on the shorter edge of the base unit.



Step 6 : Slot the other side as well.



Step 7 : Take the **B) Middle Shelf Unit (smaller piece)**. Slide down through the top of the graphic panel (wrap). Slot the other **2 D) Shelf Unit Supporting Pole (shorter pole with no screws)** into the holes of the middle shelf unit.



Step 8 : Take the **2nd A) Top/Base Unit (the larger piece)**. Slot over the wrap.



Step 9 : Slot the **1st E) Header Panel Supporting Pole (longer pole)** through the hole of the top unit.



Step 10 : Slot the **2nd E) Header Panel Supporting Pole (longer pole)** through the other hole of the top unit as well.



Step 11 : Attach the **F) Header Panel** to the top of the header supporting poles.



Finish! Ready to go!